


2.4GHz RF Remote





- 12 keys, 4 zones remote control.
- RF 2.4GHz wireless signal.
- Work with F4-3A/F4-5A/F4-CC wireless drivers to control LED fixtures.
- EX series touch panel optional.




Main Characteristics

Model	F5	F6	F7	F8
Remote Option	Dimming, 4 zones	Color temperature, 4 zones	RGB, 4 zones	RGBW, 4 zones
Working Voltage	3Vdc (Battery CR2032)			
Wireless Frequency	2.4GHz			
Working Temperature	-20 ~55			
Dimensions	L145×W40×H12(mm)			
Package Size	L150×W46×H18(mm)			
Weight(G.W.)	85g			

Operating Instruction for Remote




Wiring Diagram



Dimensions

Unit : mm



F series remote can control wireless driver directly, please refer to wireless driver manual for match code method.

F series remote can work with EX series touch panel, please refer to touch panel manual for match code method.

Match/Clear code between remotes

1. Assuming that B match up with A. Short press the bottom two keys of B simultaneously, the indicator light keeps on after release.



2. Then press any key on A in 5 seconds. When the indicator light of B turns off, match successfully.




Clear code

Press the bottom two keys of remote simultaneously (about 10 seconds) until the indicator light keeps on, deactivated the matching successfully.



2.4GHz RF 遥控器

- 12键4分区遥控器
- RF 2.4GHz 无线信号
- 结合F4-3A/F4-5A/F4-CC无线驱动器实现对LED灯具的控制
- 可与EX面板配合，实现对LED灯具的控制



FC CE RoHS



(warranty)
5 years



技术参数:


型号	F5	F6	F7	F8
遥控类型	调光, 4分区	色温, 4分区	RGB, 4分区	RGBW, 4分区
工作电压	3Vdc (纽扣电池CR2032)			
无线频率	2.4GHz			
工作温度	-20°C ~ 55°C			
产品尺寸	L145×W40×H12(mm)			
包装尺寸	L150×W46×H18(mm)			
重量(毛重)	85克			

遥控按键功能:




变化模式

1. 三色跳变
2. 七彩跳变
3. 三色渐变
4. 七彩渐变




变化模式

1. 三色跳变
2. 七彩跳变
3. 三色渐变
4. 七彩渐变
5. 静态黑色




连线示意图:



尺寸图:

单位: mm



F系列遥控器可直接控制无线驱动器，对码方法请查阅无线驱动器说明书。

F系列遥控器可与EX系列触面板配合使用，对码方法请查阅触面板说明书。

遥控器之间的对码

1. 假设 B 学习 A，同时短按 B 最下面的两个键，松开后指示灯长亮。



2. 5秒内按下 A 任意键，B 遥控器指示灯闪烁 2次，学习成功。



遥控器清码

同时长按遥控器最下面两个键 (约10秒)，直到指示灯长亮，清码成功。

